USERGUIDE

VELA TANGO 50

Tango™ 50

WWW.VELA.EU

CONTENTS

1.0. INTRODUCTION 3

1.1. SAFETY 4

1.2. WARRANTY 4

1.3. UNPACKING THE CHAIR 4

1.4. MAINTENANCE OF VELA TANGO 50 4

1.5. VELA TANGO 50 USERMANUAL 6

1.6. TECHNICAL DATA 7

1.6.1 Stability and balance 7

1.6.2. Recycling 7

1.0 INTRODUCTION

Dear Customer
We would like to thank you for purchasing a VELA Tango. We are sure that it will continue to give you pleasure well into the future. The directions for use contain useful information about positioning, operating, maintenance and technical data, etc.

This user manual applies to the VELA Tango 50.

Important
Please read this manual carefully and keep it for future reference. It must always be readily available to the user. This user manual must always be kept with the chair.

The manual is also available on VELA's website: www.vela.eu. If you have any questions, please contact VELA.

The chair is made by VELA, Vermund Larsen A/S, Goeteborgvej 12, 9200 Aalborg SV, Denmark. The VELA Tango is designed for indoor use by people with slight disabilities.

1.1. SAFETY
This chair carries the CE-mark and complies with all current EU regulations. Remove the CE-mark, when rebuilding the product or when using other than original VELA spare parts and fittings.

RECYCLING
Many of the materials used in the chair's construction can be recycled. Deliver the chair to VELA or our local recycling centre.

IMPORTANT INFORMATION
Compliace with the EMC-demand according to: IEC 60601-1-2.Be carefull under use of e.g. mobile phones, high frequency medical equipment. If you have any questions, please do not hesitate to contact VELA or your local dealer.

DISTRIBUTOR:

1.2 WARRANTY

his warranty applies only to products purchased in the United States through our authorized partner Ri LLC. VELA A/S warrants this product to be free from any defects in material or workmanship. The warranty only applies to the original purchase and terminates if you transfer, modify or sell the product.

Warranty period:

- Frame, backrest arm, armrest bars and armrest fixture – Lifetime (the time you own it)
- Seat mechanism, gas spring or electric actuator – 2 years
- Others, except high-wear items including, but not limited to, castors, textiles and batteries – 1 year

This warranty does not apply to normal wear and tear to products, nor to high-wear items. This warranty does not cover fading, discoloration or natural variations occurring in leather and fabrics. This warranty does not apply to normal wear and tear or damage caused by accident, neglect, misuse or improper installation or operation. This warranty does not cover damage caused by a carrier of transportation of the product, alterations made by owner, or customer´s own material.This warranty is based upon a single 8-hour shift usage only.

If there is a defect within the warranty period you shall send a written notice of the defect to VELA's US partner Ri LLC. Ri LLC and VELA will decide if the defect is to be repaired or replaced by a new product.

Please read the user manual carefully for information on correct maintenance of the product.

REPAIR

If there is a fault on your chair you should contact your dealer at once. Defective chairs should not be used. If your chair needs reconditioning or repair, only original VELA parts must be used.

Accessories or available spare parts which are broken can be forwarded to VELA for repair. If fault in the fundamental parts, the whole chair need to be returned to VELA for repair. R82 will not be held responsible for damage or injury caused by use of non-original parts or repairs made by a non-authorized VELA person.

1.3. UNPACKING THE CHAIR

VELA Tango is supplied in cardboard packaging which is developed and produced to ensure the least possible impact on the environment and with focus on ease of use. In case of defects or transport damage to the chair, please contact VELA immediately. You must not try to repair any damage yourself or start using the chair.

The box in which the chair was supplied should contain:

- VELA Tango fitted with any additional accessories
- This user manual

1.4. MAINTENANCE OF VELA TANGO

We recommend that you have your VELA Tango serviced once a year to identify any

defective or worn parts. However, removable parts should be regularly checked and tightened. When adjustments have been made, then make sure to tighten up. It is important to fasten all screws on the chair on a regular basis. All screws which secure the accessories have to be checked, at least once a month. Further, it is important to be aware of any indications of beginning faults on the frame, PVC parts and the like.

The gasspring functions without any maintenance. Do not expose the gasspring to pressure, high temperatures or perforation

Wheels
Wheels should be regularly checked and cleaned of any fluff etc.

Base
Wash regularly with a mild solution of lukewarm water and pH-neutral washing-up liquid.

Upholstery
The fabric is made of polyester, which only needs to be vacuumed occasionally and wiped with a cloth rinsed in clean water and tightly wrung. Make sure to remove any stains as quickly as possible. Always use a moist clean, white cotton cloth. For more stubborn stains, use a bit of mild washing-up liquid. Do not use any cleaning materials containing chlorine or methylated spirit. Any incontinence cover should be machine-washed on a gentle cycle.

1.5. GENERAL INSTRUCTIONS

To ensure correct use of the VELA Tango, please note the following:

TRANSPORTATION
Always remember to lock the chair in position when transporting VELA Tango. No one should sit in the chair while it is being transported.
Temperature during transport: -104 degrees to +158 degrees
Humidity: 15%-95%
Air pressure: ppp up to 0.6 miles above sea level

STABILITY AND BALANCE
VELA Tango is designed to be used on a daily basis at work or in the home. It is intended for quiet, seated work. All movements in VELA Tango have a bearing on the chair's centre of gravity. To enhance safety, we recommend the following:

- Maximum user weight is 275 lbs., however the level of activity is a key factor. A person with extreme movements in the chair should contact a sales consultant before purchase
- The chair is not intended for standing on
- When moving the chair, it should always be locked

1.5 VELA TANGO 50 USERMANUAL

◀ HEIGHT ADJUSTMENT
The height of the VELA Tango 50 can be adjusted using the gas springs. This is done by pulling the small lever under the seat. (left side)

◀ BACK-HEIGHT
The back can be adjusted by pulling the lever. The lever can be found behind the seat.

◀ ARMREST
The height as well as the width of the arm rests can be adjusted.

HEIGHT-ADJUSTMENT
The height is adjusted by loosening the lever. Remember to tighten them well again.

WIDTH-ADJUSTMENT
The width is set by loosening the lever and adjusting the width.
Remember to tighten the levers again.

◀ BRAKE
VELA Tango 50 has a centralbrake. The hand-brake is pushed forwards to lock the wheels and backwards to release them.

◀ Folding foot ring
You can push the folding foot ring up and down just by pushing the ring with your foot.

1.6. TECHNICAL SPECIFICATIONS

	VELA Tango 50
Height adjustment	Gas, 350N
Seat	17,3 x 17,3 inches
Seat depth	14.5 - 17.3 inches
Back	14.5 x 11.8 inches
Back tilt	-10° / +13°
Armrest PU	3.5 x 11.8 inches
Armrest height	0-9,4 inches
Armrest spacing	14.5 - 20 inches
Sitting height. Please note that the height cannot be changed after delivery.	Model 1: 15.7 - 21.6 inches Model 2: 17.7 - 23.6 inches
Frame	21.6 x 21.6 inch
Weight	44 lbs.
Max. load	275 lbs.

1.6.1. STABILITY AND BALANCE

The VELA Tango is designed as an everyday chair at home. It is intended for sedentary work and not as a wheelchair. All movement in the VELA Tango have an impact on the placement of the centre of gravity.

To increase the safety, we recommend:

- Maximum user weight is 275 lbs., however the activity level is a significant factor. A person with very forceful movements using the chair should contact a sales consultant from VELA/VELA Distributor before purchase
- Do not stand on the chair
- Do not stand on the footring. It is only intended for getting on and off
- The chair is not intended as a wheelchair
- During transportation, the chair should always be locked

1.6.2. RECYCLING

Some of the chair's material can be recycled. Deliver the chair to VELA's distributor or your local recycling installation.

VELA · Goeteborgvej 12 · 9200 Aalborg SV · Denmark · Tel: +45 96 34 76 00 · mail@vela.dk · www.vela.eu

VELA Tango 50 1-2011/USA